

F012-P

Programming Instructions for “FAST SETUP” Totalizers ONLY

1. **Push and hold** program/enter button until screen changes and says “SETUP 01 FAST”
2. Touch select. LCD screen will not read “PART 02 TM0038 (the turbine meter part number could differ if the monitor had been previously programmed and another model number had been selected).
3. Touch program/enter button (the program bar will flash on the LCD display) press select and scroll through the turbine meter model numbers and stop on the size meter you have. Touch program/enter to save your selection.
4. Touch select. The display will now read “SETUP UNIT 03 GAL”.
5. Touch program/enter button (the program bar will flash on the LCD display) and touch select to scroll through, then stop on the unit of measure you desire. Press program/enter to save your selection.
6. Touch select. The display will now read “SETUP 04 time/min. Touch program/enter button (the program bar will flash on the LCD display) touch select and scroll through the different time bases. Touch program/enter to save your selection. Time bases are sec-second, min-minute, HR-hour, and day. These time bases are used in the flow rate or bottom display only. EXAMPLE: GALLONS PER **MINUTE**, BARRELS PER **DAY**, etc.
7. **Push and hold** program/enter button until LCD screen changes back to the regular screen or run mode. Programming is now complete!